


# *LifeFitness*

**Arctic Silver 93TW Treadmill**



**Customer Support Services**  
***PARTS MANUAL*** rev 03 Jul 2008

OPERATION MANUAL	M051-00K58-A173
SERVICE MANUAL	M051-00K58-A159
HARDWARE BAG	AK58-00227-0000
ACCESS-PLATE ASSY. ASSEMBLY INCLUDES: 1) CONNECTOR PLATE 2) F TYPE CONNECTOR	AK58-00329-0000  0K58-01392-0000 0017-00021-2846
TOUCH UP PAINT: SPRAY CAN .5 OZ BOTTLE W/APPLICATOR .33 OZ PEN	  0017-00008-0204 0017-00008-0205 0017-00008-0206
INSTALLATION VIDEO	M051-00K58-A098
SERVICE VIDEO	M051-00K58-A099

**NOTE: ADDING THE BOLT-ON LCD SCREEN TO THE  
93TW-XXXX-03 MAKES THE UNIT A 93TER-XXXX-03.**


	Page
REAR ENDCAPS AND CUP HOLDERS .....	4
SCUFF PAD, TINSEL AND FRAME TAG BOARD .....	5
CONSOLE AND RELATED COMPONENTS.....	6
UPRIGHTS, HAND RAILS AND ERGO BAR .....	7
MOTOR COVER, FRONT COVER AND ENDCAPS .....	8
BELT, DECK AND REAR ROLLER.....	9
LIFT FRAME AND MOTOR .....	10
WAX/LIFT ASSEMBLY .....	11
MOTOR CONTROLLER ASSEMBLY.....	12
DRIVE MOTOR ASSEMBLY .....	13
IDLER ARM ASSEMBLY AND STATIC BRUSH.....	14
LEG LEVELER ASSEMBLY .....	15
FRONT ROLLER ASSEMBLY .....	16
POWER COMPONENTS SCHEMATIC .....	17
CABLES .....	18

## ARCTIC SILVER 93TW

### Rear End Caps and Cup Holders

93TW-0XXX-03

S/N AWJ100000 and up




## ARCTIC SILVER 93TW

Scuff Pad, Tinsel and Frame Tag Bd.

93TW-0XXX-03


S/N AWJ100000 and up



# ARCTIC SILVER 93TW

## Console and Related Components

**93TW-0XXX-03**  
**S/N AWJ100000 and up**




Console Assembly	Overlay/Bezel/Switch Assy.	Overlay	Language
AK58-00439-0001	AK58-00204-0001	OK58-01300-0001	Eng/Met
AK58-00439-0002	AK58-00204-0001	OK58-01300-0001	Eng/Eur
AK58-00439-0003	AK58-00204-0003	OK58-01300-0003	German
AK58-00439-0004	AK58-00204-0004	OK58-01300-0004	Spanish
AK58-00439-0006	AK58-00204-0006	OK58-01300-0006	Japanese
AK58-00439-0007	AK58-00204-0007	OK58-01300-0007	French
AK58-00439-0008	AK58-00204-0008	OK58-01300-0008	Italian
AK58-00439-0009	AK58-00204-0009	OK58-01300-0009	Dutch

# ARCTIC SILVER 93TW

## Uprights, Handrails and Ergo Bar

93TW-0XXX-03

S/N AWJ100000 and up




## ARCTIC SILVER 93TW

### Motor Cover, Front Cover and Front End Caps

93TW-0XXX-03

S/N AWJ100000 and up







# ARCTIC SILVER 93TW

## Belt, Deck and Rear Roller

**93TW-0XXX-03**  
**S/N AWJ100000 and up**





## ARCTIC SILVER 93TW

### Lift Frame and Lift Motor

93TW-0XXX-03

S/N AWJ100000 and up




# ARCTIC SILVER 93TW


Wax/Lift Assembly-AK58-00243-0000

93TW-0XXX-03

S/N AWJ100000 and up




**AK60-00171-0000 (100-120v) W/O FERRITE**  
**AK60-00171-0001 (200-240v) W/O FERRITE**  
**AK60-00171-0002 (100-120v) WITH FERRITE**  
**AK60-00171-0003 (200-240v) WITH FERRITE**



# ARCTIC SILVER 93TW

## Drive Motor Assembly

**93TW-0XXX-03**  
**S/N AWJ100000 and up**




Drive Motor Assembly Number	Motor Serial Number
AK58-00172-0000	AWJ100000 – AWJ100020
AK58-00172-0002	AWJ100021 and up

## ARCTIC SILVER 93TW

### Idler Arm Assembly and Static Brush

93TW-0XXX-03

S/N AWJ100000 and up




## ARCTIC SILVER 93TW

Leveler Assembly – AK58-00370-0000


93TW-0XXX-03

S/N AWJ100000 and up



**ARCTIC SILVER 93TW**  
**Front Roller Assy.-AK58-00066-0000**

**93TW-0XXX-03**  
**S/N AWJ100000 and up**






# ARCTIC SILVER 93TW

## Power Components Schematic

**93TW-0XXX-03**  
**S/N AWJ100000 and up**



# ARCTIC SILVER 93TW

## Wax/Lift Power Supply

93TW-0XXX-03

S/N AWJ100000 and up

